

Sparepart documentation

Kein Bild

[Plate dispenser unheated 2 SE 21-26](#)

Prod. No.: 591002

Spareparts

Image	Code	Name	Quantity in device
	146220	CORNER PROTECTOR <i>(valid from 09/01/1997)</i>	1.0 Each
	146680	EXPAND. NUT 72.30.459 F. SHEET SCRW. 4.2 <i>(valid from 09/01/1997)</i>	3.0 Each
	146223	Stopper f. corner protector RAL 7024 <i>(valid from 09/01/1997)</i>	4.0 Each
	376900	Plate guide complete RAL7043 <i>(valid from 03/18/2014)</i>	4.0 Each
	376904	Cover cap RAL 7043 <i>(valid from 03/18/2014)</i>	4.0 Each
	147973	Carrier small <i>(valid from 09/01/1997)</i>	2.0 Each
	146304	Tension spring 4GR <i>(valid from 09/01/1997)</i>	8.0 Each

Image	Code	Name	Quantity in device
	<u>146305</u>	Tension spring 8GR (valid from 09/01/1997)	16.0 Each
	<u>147971</u>	Basket small (valid from 09/01/1997)	2.0 Each
	<u>83589</u>	NUT, WELD, SNO 5601 VERS. C F.3.5 ST. (valid from 09/01/1997)	4.0 Each
	<u>81166</u>	Tapping screw 3,5X9,5 DIN 7981 1.4301 (valid from 09/01/1997)	8.0 Each