

Sparepart documentation

Kein Bild

[Platform dispenser heated CHV-57/57](#)

Prod. No.: 591014

Spareparts

Image	Code	Name	Quantity in device
	385096	Seal 9x5,5 black (valid from 02/05/2020)	1.0 Meter
	146220	CORNER PROTECTOR (valid from 08/28/1997)	1.0 Each
	146680	EXPAND. NUT 72.30.459 F. SHEET SCR. 4.2 (valid from 08/28/1997)	3.0 Each
	146223	Stopper f. corner protector RAL 7024 (valid from 08/28/1997)	4.0 Each
	146302	Tension spring 20GR (valid from 08/28/1997)	8.0 Each
	146305	Tension spring 8GR (valid from 08/28/1997)	4.0 Each
	290946	Tray cpl. 58/58 (valid from 08/28/1997)	1.0 Each

Image	Code	Name	Quantity in device
	<u>146285</u>	BEARING,STEEL- (valid from 08/28/1997)	20.0 Each
	<u>83589</u>	NUT, WELD, SNO 5601 VERS. C F.3.5 ST. (valid from 08/28/1997)	8.0 Each
	<u>81166</u>	Tapping screw 3,5X9,5 DIN 7981 1.4301 (valid from 08/28/1997)	12.0 Each
	<u>105708</u>	Tubular heater 1800W Nr. 20.28907.000 (valid from 08/28/1997)	1.0 Each
	<u>105805</u>	Safety temperature limiter 135 °C (valid from 08/28/1997)	1.0 Each
	<u>107649</u>	Spiral cable Europe 3x1,5 qmmst WG (valid from 03/03/2021)	1.0 Each
	<u>106304</u>	Cable gland M20x1.5 black (valid from 08/28/1997)	1.0 Each
	<u>106311</u>	Hexagon nut M20x1.5 (plastic) (valid from 08/28/1997)	1.0 Each
	<u>105798</u>	MAINS SWITCH (valid from 08/28/1997)	1.0 Each
	<u>146902</u>	FIXING COLLAR (valid from 08/28/1997)	2.0 Each
	<u>105429</u>	terminal block Wieland KL 24/3 SL (valid from 08/28/1997)	1.0 Each
	<u>296814</u>	Cover hood square 58/58 (valid from 08/28/1997)	1.0 Each

Image	Code	Name	Quantity in device
	<u>106184</u>	Warning sign hot surface <i>(valid from 08/28/1997)</i>	1.0 Each
	<u>358964</u>	Label-no plastic <i>(valid from 08/28/1997)</i>	1.0 Each